

Intelligent Battery Status Indicator

INDICATES VOLTAGE LEVELS AND CHARGING OR DISCHARGING



What state is your battery in right now?

Can you rely on it to do what it needs to?

- Is it being charged, or discharging?
- Is it "up" or does it need more charging?
- or is it so flat that it needs a full overnight charge?

Usually the first indication is when it lets you down.

The Antares battery status indicator displays battery voltage levels and shows whether the battery is going up or down (being charged or being dis-charged).

Clever use of just three LEDs provides an immediate, on-demand, visual indication that is useful to any driver/operator: It shows when the battery is being charged, when it is fully charged, when it's "good to go" and so on, and with added flash patterns will warn the operator of over- or under-voltage.


KEY FEATURES

- Part No 90400
- Simple press button indication
- 12V and 24V auto sensing
- LEDs normally off - doesn't distract - very low power (1.6mA and 28mA when lit)
- Provides critical information on VRLA lead acid batteries
- Displays voltage levels and charging or discharging
- Special flash pattern to show charging is required
- Over-voltage indication
- Additional reminder label shows all reported statuses
- IP44 Flush mounted panel
- CE and e-mark certified
- Volt free alarm contacts
- 24 months warranty
- Size 76 x 42 x 29(H) mm
- Weight 30g

Antares TDC
Knaves Beech Business Centre
Davies Way
Loudwater
HIGH WYCOMBE
HP10 9QR UK

www.antares.co.uk
email: info@antares.co.uk
tel: +44 (0)1628 535440
fax: +44 (0)1628 535441

ANTARES
engineering with answers



Additional reference label confirms meaning